

BANG & OLUFSEN

BEOLAB 2000

This manual was scanned by
and available FREE at www.lconic-AV.co.uk



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



CAUTION: To reduce the risk of electric shock, do not remove cover (or back).

No User-serviceable parts inside. Refer servicing to qualified service personnel.

WARNING: To prevent fire or electric shock, do not expose this appliance to rain or moisture.



This symbol indicates that a dangerous voltage constituting a risk of electric shock is present within this unit.



This symbol indicates that there are important operating and maintenance instructions in the literature accompanying this unit.

For the US-market only!

NOTE: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**This manual was scanned by
and available FREE at www.iconic-AV.co.uk**

For the Canadian market only:

This class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Note: Building and electrical codes may vary from locality to locality. Make sure that the installation is in compliance with applicable codes. Bang & Olufsen shall not be legally responsible for injury or damage caused by improper installation.



This guide describes how to install your BeoLab 2000 in a BeoLink (ML) distribution system.

If you have never carried out cable installation before, we suggest you leave it to your Bang & Olufsen dealer. We recommend that you follow the instructions in this guide carefully.

The User's guide, which is also supplied with the BeoLab 2000, describes how to operate the system once it has been installed.

The BeoLink distribution system enables you to control your main system and to listen to it in the link room. Your link room must be connected to the main room via a Master Link cable. To join the Master Link cables from the main system and from the BeoLab 2000 a Master Link junction box is required. The accessories can be purchased at your Bang & Olufsen dealer.

The main room is the room in which you have placed your audio system and/or video system (the main system). *The link room* is where you are about to set up your BeoLab 2000.

When you set up your BeoLab 2000, we recommend the following sequence:

- 1 Switch off your Bang & Olufsen system and disconnect it from the mains.
- 2 Make the installation as described in this guide.
- 3 Connect the entire system to the mains.

This manual was scanned by
and available FREE at www.iconic-AV.co.uk

