



Guide



This manual was scanned by
and available FREE at www.Iconic-AV.co.uk

This Guide explains how to operate your BeoCenter 2. It will guide you through the operations available for your system. All instructions regarding setting-up and the Socket unit are found in the separate Guide included with the Socket unit.



A typical page in this Guide is laid out in the following way:

A

An illustration explaining the menus.

B

The basic idea of the described menus or functions.

C

List of the menu items.

D

Additional useful information, specific circumstances which may occur during operation, or conditions which may need to be fulfilled.

How to use your music system, 4

Find out how to switch on and operate sources, such as CD, radio or DVD via the close-up operation panel

How to read the menu symbols, 6

Get an explanation to the symbols which appear in the menus

How to use the menus, 7

Find out how to move around in menus and how to make settings in fill-in menus

First-time setup, 8

Find out about the first-time setup procedure

Call up additional sources, functions and menus, 9

See which functions, features and menus can be activated via the close-up operation panel

Tune in and edit radio programs, 10

Find out how to tune in, move, name and delete radio programs

Audio CD settings, 11

Find out how to activate special CD playback functions, how to name and edit CDs

Make your music system start and stop automatically, 12

Find out how to name and activate Timers

Make sound settings, 13

Find out how to set your own preferences for volume, bass, treble, balance and loudness

Make option settings, 14

Find out how to change the basic settings of your music system

How to use the pincode system, 15

Find out how to activate and use the pincode system

DVD operation, 16

Find out how to play a DVD and to use the DVD menus on the television screen. Settings for the DVD OPTIONS menu on BeoCenter 2 are also explained

Use the Beo4 remote control, 19


Find out how to use the Beo4 remote control and operate your music system from a distance

Index, 20

How to use your music system

Your music system is designed for close-up operation. Use the music system to listen to radio or CD. Just press a single button on the close-up operation panel to listen to the sound of your choice.

Slide your finger around the 'wheel' to adjust volume.



Switches on the radio	RADIO	◀ ▶	Searches through a CD, steps between folders in N.MUSIC mode*, and moves the cursor sideways in menus
Starts playback of a loaded disc	DISC	▲	Steps between radio programs, tracks on a CD or in N.MUSIC mode* and moves the cursor up or down in menus
Opens and closes the disc compartment	LOAD	▼	
Brings up extra sources, functions and menus in the display	LIST	GO	Enters fill-in menus, confirms and stores choices in menus. While listening to a CD, press to pause playback, press again to resume playback
Selects radio programs, tracks on a CD, or N.MUSIC* tracks, or menu items	0 – 9	●	Brings up the subtitle menu when watching a DVD
Steps back one level in the menu system or leaves the menu system	EXIT	●	Brings up the disc menu when watching a DVD
Switches BeoCenter 2 to standby	●	●	Brings up the audio language menu when watching a DVD
		●	Calls up the camera angle menu when watching a DVD

*NOTE! The coloured buttons are also used when listening to N.MUSIC, refer to the BeoLink PC 2 Guide for further information.

This manual was scanned by
and available FREE at www.iconic-AV.co.uk

