



Bevi 3 m 2

Guide

This manual was scanned by
and available FREE at www.lconic-AV.co.uk



350721801

BANG & OLUFSEN **B&O**

BeoCom 2

Key

Display

- > An up arrow ▲ or a down arrow ▼ on the display indicates that there is more information available than is shown on the display. This information can be accessed by moving the Track point in the direction of the arrow.


Track point and keys

- > The Track point is your cursor for operating the functions shown on the display. The operation sequences indicate in which direction(s) (▲ ▼ ◀ ▶) to move the Track point.

Keys

- > The operation sequences show the keys you have to press.

Where sequences are solely repetitions, the Track point and keys are only shown once.



OK

Although the phone is an everyday object for people today, there is no need for it to be invisible. BeoCom 2 has a unique design and a specially composed ringer signal which alerts you to calls without being intrusive.

BeoCom 2 is a cordless phone with a range which allows you to move freely around your home while you are talking.

The phone is operated via the display and the Track point on the handset keypad.

BeoCom 2 is available in two versions: as a wall-mounted model, where the base is fixed to the wall, and as a table-top model. There is no difference in operation between the two models.



Connecting your BeoCom 2

- 6 Placement and surroundings
 - technical data
 - placement of the table-top model
 - installing the wall-mounted model
- 7 Phone maintenance and cleaning
- 8 Connecting the base to the phone network and the mains
 - how do I get the handset and base to work?
- 8 Special features of your BeoCom 2
- 9 Charging the handset battery
 - how and for how long must the battery be charged?
- 10 Setting the time and date

Key pad and display

- 11 Handset keys
 - what does each key do?
- 12 Handset display
- 13 Understanding the information on the display

Daily use – making and answering calls

- 14 Making and ending calls
- 14 Answering a call
- 15 Adjusting the volume of the handset during calls
- 15 Turning the microphone off

Phonebook

- 16 Storing a name and number in the Phonebook immediately after a call
 - entering a name
- 17 Entering a new name and number in the Phonebook
- 18 Searching the Phonebook and making a call
- 19 Editing a name and number in the Phonebook
- 20 Deleting entries from the Phonebook

Extension numbers – calling and storing

- 21 Calling an extension number

Redial

- 22 Information on Redial
 - seeing the names and numbers of outgoing calls
- 22 Calling from the Redial list
- 22 Storing a Redial number in the Phonebook
- 23 Deleting entries from the Redial list

Caller ID

- 24 Caller ID information
 - seeing the names and numbers of incoming calls
- 24 Calling from the Caller ID list
- 24 Storing a Caller ID number in the Phonebook
- 25 Deleting entries from the Caller ID list

Audio Video system

- 26 Adjusting the volume on your Bang & Olufsen Audio, Video or Link system

Settings

- 27 Adjusting the ringer signal
 - setting the ringer signal volume
- 27 Setting the time and date
- 27 Switching off the display of new calls
- 27 Switching off auto offhook
 - do you want the phone set up so that you do not need to press the Call button to answer a call?
- 27 Setting the language
- 27 Resetting Redial and Caller ID
 - deleting numbers and names from Caller ID and the Redial list

For your information...

- 28 For your information
- 29 Conditions of the guarantee

