

BeoLab 3500

User's guide

This manual was scanned by
and available FREE at www.Iconic-AV.co.uk

BANG & OLUFSEN



The BeoLab 3500 gives your main Bang & Olufsen system an extra dimension. Now you can play any source you like in your main system and listen to it – via your BeoLink installation – in the room with your BeoLab 3500.

The BeoLab 3500 can be operated both locally and with remote control. With remote control, however, the possibilities are enhanced and you are given the full benefit of your BeoLab 3500.

You can control the daily playback functions in your main system, make the BeoLab 3500 wake you up in the morning, using the Beo4 remote control.

Whether you hang it on the wall or place it standing on its own in the specially designed stand (optional extra), the slim and elegant BeoLab 3500 will fit easily into any room in your house where you want music.

The separate Setting-up guide enclosed with the BeoLab 3500 describes in detail how to install the system (BeoLink or MCL) and make the BeoLab 3500 ready for use.

Note: Bang & Olufsen offers two different BeoLink distribution systems: Master Link (ML) and Master Control Link (MCL). Your BeoLab 3500 can be used in either system.

4 What can BeoLab 3500 do for me...

..Music in other rooms

6 Beo4 remote operation

6 *Using the Beo4 remote control*

8 *Access all your sources in your main A/V system with Beo4*

10 *Adjust and make sound settings in the BeoLab 3500 with Beo4*

12 *Make a Wake-up Timer for BeoLab 3500 only*

14 Close-up operation

14 *BeoLab 3500 and Timer play – switching on automatically*

15 *How to get and mute sound in BeoLab 3500*

16 *Read the display on BeoLab 3500*

17 *Choose which information to display on the BeoLab 3500*

18 BeoLab 3500 status displays

20 Beolink 1000 remote control

Using the Beolink 1000


The BeoLab 3500 gives your main Bang & Olufsen system an extra dimension:

- It enables you to listen to any source you like from your main room system in the room with your BeoLab 3500.
- It enables you to control a number of functions in your main system from the room with your BeoLab 3500 – using the Beo4 remote control. All remote operation are, though, also possible with a Beolink 1000 remote control, see pages 20-21.

All you have to do is connect the BeoLab 3500 to your BeoLink installation, and your main Bang & Olufsen system can be used in that room as well.

The two active speakers in the BeoLab 3500 will give you the full benefit of the high-quality stereo sound produced by your main Bang & Olufsen system.

This guide explains how...



Your main Bang & Olufsen system and your BeoLab 3500 must be interconnected by a BeoLink (ML or MCL) installation. You will then be able to listen to any source from your main audio-, video-, or AV system (and even to control the source) in the room with your BeoLab 3500.



Using the Beo4 remote control, you can:

- Switch on any source you like in your main Bang & Olufsen Audio/Video system via the BeoLab 3500.
- Operate all the daily playback functions for the source that is currently playing via the BeoLab 3500.
- Adjust the sound in your BeoLab 3500 speakers.
- Make a Wake-up Timer on your BeoLab 3500.

Operating the BeoLab 3500 close-up, you can:

- Switch on to the source that was last playing in your main Bang & Olufsen system, or listen-in on a source that is currently playing.
- Include the BeoLab 3500 in a Timer Play programming made on your main room A/V system, that is, switching on at a certain time to a certain source, as programmed on your main room system.

The Beo4 remote control* gives you the full benefit of your BeoLab 3500.

When you operate the BeoLab 3500 close-up, you will either switch on a source that was last playing in your main Bang & Olufsen system, or you will listen-in on a source that is currently playing.


The Beo4 remote control enables you to switch on to the exact source you wish to listen to from your main Bang & Olufsen system (audio or video), and to control the daily playback functions for that source.

The daily playback functions are carried out just as if you were operating your main system directly, using the Beo4 remote control.

With Beo4, you are given the opportunity to make a Wake-up Timer on BeoLab 3500 which is executed separately, regardless of whether you have included BeoLab 3500 in a Timer Play programming or not – which, via your main room system, switches all linked products on automatically at a certain time to a certain source.

Furthermore, the Beo4 is the key to adjusting the sound for the BeoLab 3500 speakers separately.

See how on the next few pages...



Any operation you carry out using the Beo4 remote control is received by your BeoLab 3500. Via your BeoLink installation, the BeoLab 3500 communicates your instruction to your main Bang & Olufsen system.

