



Beomaster

3300

This manual was scanned by
and available FREE at www.lconic-AV.co.uk

Bang & Olufsen

Beosystem 3300



This manual was scanned by
and available FREE at www.Iconic-AV.co.uk

The Beomaster 3300 receiver is the master of the Beosystem 3300. The other units in the Beosystem 3300 are:

- the Terminal 3300 remote control*
- the Beocord 3300 tape recorder*
- the Beogram CD 3300 compact disc player*
- the Beogram 3300 record player*

The sloping sensi-touch panel on the front gives access to all the primary functions. All you have to do is touch the area below the appropriate text or symbol.

The switches and controls underneath the hinged aluminium lid give access to all the secondary functions.

To open the lid press the extreme left-hand side of the narrow front strip. Close the lid again by pressing it down gently until you hear a 'click'.

**This manual was scanned by
and available FREE at www.lconic-AV.co.uk**

