

Beovox Penta



This manual was scanned by
and available FREE at www.Iconic-AV.co.uk

Bang & Olufsen

Table of contents

Assembling stand and column	4
Connection to receiver	5
Placement	6
Maintenance	6
Technical specifications	7

This manual was scanned by
and available FREE at www.lconic-AV.co.uk



This manual was scanned by
and available FREE at www.Iconic-AV.co.uk


Your Beovox Penta is the jewel in the Bang & Olufsen loudspeaker range. It is a 150 watt loudspeaker designed on the basis of Bang & Olufsen's newly developed acoustic technologies. It has the shape of a pentagon with no parallel inner surfaces, which according to acoustic principles prevents unwanted reflections within the loudspeaker.

The Beovox Penta fits naturally into any home environment. It takes up very little floor space and adopts the colours of its surroundings.

Because of its slim, column-like design it can be placed freely without special attention to room configuration, walls or anything otherwise affecting the performance of a loudspeaker. Any requirements to placement will only be of a visual nature.

**This manual was scanned by
and available FREE at www.lconic-AV.co.uk**

Assembling stand and column



Assembling the stand and the column is easiest if the column is lying on a table. In order to protect the table against being scratched, we recommend you first place the wrapping foam on the table.

The only tool you require for assembling is a spanner which is included with the loudspeaker.

First of all unscrew the five bolts inserted in the holes on the base of the column. Then fasten the stand to the column by reinserting the five bolts and tightening them using the spanner. Please also refer to the diagrams.

