BeoCenter 2

Guide



BANG & OLUFSEN

Contents

This Guide explains how to operate your BeoCenter 2.

It describes operation of BeoCenter 2 both with and without DVD function. This means that information about DVD functions is included in the Guide whether your BeoCenter 2 is equipped with DVD or not.

Instructions regarding setting-up and the Socket unit are found in the separate Guide included with the Socket unit.

How to use your music system, *4*
Find out how to switch on and operate sources via the close-up operation panel

How to read the menu symbols, *6*
Get an explanation to the symbols which appear in the menus

How to use the menus, *7*
Find out how to move around in menus and how to make settings in fill-in menus

First-time setup, *8*
Find out about the first-time setup procedure

Call up additional sources, functions and menus, *9*
See which functions, features and menus can be activated via the close-up operation panel

Tune in and edit radio programs, *10*
Find out how to tune in, move, name and delete radio programs

Audio CD settings, *12*
Find out how to activate special CD playback functions, how to name and edit CDs

Make your music system start and stop automatically, *13*
Find out how to name and activate Timers

Make sound settings, *14*
Find out how to set your own preferences for volume, bass, treble, balance and loudness

Make option settings, *15*
Find out how to change the basic settings of your music system

How to use the pincode system, *16*
Find out how to activate and use the pincode system

DVD operation, *18*
Find out how to play a DVD and how to use the DVD menus on the television screen.

Use the Beo4 remote control, *22*
Find out how to use the Beo4 remote control and operate your music system from a distance

Index, *23*